

KOOL TACK

INSTRUCTIONS

Kool Tack is the only drymount foam board that works at 150°F to 160°F

KoolTack is the most forgiving drymount foam board you will ever use.

Set the temperature at 150°F to 160°F, and you are ready to drymount most any print, poster, or piece of art. All it takes is 15 to 20 seconds.

Trouble shooting questions:

My picture is bubbling !

1. Check the temperature. It may be too hot. Because of the lower operating temperature of KoolTack the outside surface of the print will heat up faster, and seal the moisture, and air inside the drymount may be trapped.
2. In high humid areas, or during the summer months when the humidity is higher, it is a good practice to dry out the print prior to drymounting. This will eliminate excess moisture in the print, and give you a better drymount.
3. The temperature is too low. Check to see that your press is in fact operating at 150°F to 160°F, and put the print back into the press.

My drymount has a speck of dirt under it !

Don't worry, simply take a warm hair dryer, or warm air blower, and gently heat the corner of the print that is closest to the dirt speck, and while warming the surface of the print gently lift the print off the KoolTack board while continuing to heat the picture. Continue lifting the print until you reach the dirt speck, and remove the dirt. Be careful not to over heat the print or you may damage it. You can now repress the print in the exact same position that it was in.

My drymount isn't smooth !

The "**Orange Peel**", effect that is so prominent with drymounting is caused from two sources.

1. The temperature of the drymount board needs to be so high that the surface of the board gets soft and reduces its firmness.
2. The release board and release paper has small "hills and valleys", on the surface which impress themselves into the print.

This problem can be permanently solved with the application of a sheet of Perma Lon to the Platen of the press.

For more information call your local distributor or Tack 1 Technologies LLC.

28417 Laura Ct., Elkhart IN. 46517 Phone (888) 610-5663 Fax. (888) 593-1134